



## **EXUSTAR REPLACEMENT CLEATS**

### **FOR EXUSTAR & CLIP-IN PEDALS**

**PLEASE READ INSTRUCTIONS CAREFULLY.**  
Exustar recommends that the following procedures are performed by a professional bicycle dealer.

**\*This package includes :**

- Two cleats.
- Two adjustable cleat washers
- Four 4mm Allen bolts
- Two insole washers
- Two flat nuts

#### **INSTALLATION:**

1. Remove old cleats with a 4mm Allen key.
2. Remove the old sticker seal and other hardware.
3. Lubricate Allen bolts prior to assembly.
4. Using the hex key, tightly (recommended torque : 50-80kgf/cm) attach new cleats and hardware so that the cleats are about 1 cm behind the ball of the foot or according to preference.



#### **MAINTENANCE:**

- Replace cleats that are badly worn.
- Keep cleats and pedals clean for best performance.
- Always ensure cleats are tightly attached to cycling shoes before each ride.
- If you have any questions regarding the installation, use, shoe/pedal compatibility or maintenance of these cleats or Exustar pedals, talk to your Exustar dealer.

Check with your dealer for advice on cleat/pedal configuration.  
Refer to detailed instructions supplied with your clip-in pedals.  
Refer to shoe manufacturer instructions for more shoe-specific information.

- E-C01
- E-C02T
- E-C03
- E-C04



**EXUSTAR ENTERPRISE CO., LTD.** Specifications are subject to change without notice.  
check us out on the web at [www.exustar.com](http://www.exustar.com) Copyright Exustar Enterprise Co., Ltd. 2003.  
Made in Taiwan-Fabrique en Taiwan 7-03 EXUSTAR Part no. EPB018